

THE *Byron Fergus* LEGEND SERIES™ Long Bow Assembly Guide

1 Begin by attaching the upper limb (with signature) to the top of the riser.



2 Firmly slide the notched end of the limb into the riser (bird's beak). The signature on the limb should be facing the front of the riser.



3 Repeat with bottom limb (serial number decal facing back of riser).



4 Lay the string so that the short part of the finger protector is toward the top of the bow.



5 Place the top loop of the string loosely around the top limb and slide it down to create slack in the string.



6 Place the bottom loop of the string inside the grooves (notch) of the bottom limb tip. Make sure the string is centered on the limb.



7 Place the bottom limb tip on the side of your shoe sole (not under your shoe).



8 While pulling toward you on the riser handle, use your other hand to push the top limb away from you.



9 While pushing away, use your thumb and index finger to slide the top loop into the top limb string groove.



10 The string should be centered on the limbs. Your bow is now ready to shoot.



*Always unstring your bow when not in use.
To unstring the bow, reverse the above process.*



www.LegendBows.com
101 Archery Way • Ashley, IN 46705 • (855) 694-6784

© 2016 Global Archery Products, Inc. All Rights Reserved. #BFLB.20160414