

## LONGBOW ASSEMBLY GUIDE



**1**  
Begin by attaching the upper limb (with logo) to the top of the riser.



**2**  
Firmly slide the notched end of the limb into the riser. The signature on the limb should be facing the front of the riser.



**3**  
Repeat with bottom limb (serial number decal facing back of riser).



**4**  
Lay the string so that the short part of the finger protector is toward the top of the bow.



**5**  
Place the large top loop of the string loosely around the top limb.



**6**  
Slide the top loop down to create slack in the string.



**7**  
Place the bottom loop of the string inside the notch of the bottom limb tip. Make sure the string is centered on the limb.



**8**  
With the bow facing up, place the bottom limb under under your thigh (above and behind your knee).



**9**  
Grip the riser and pull it toward you while pushing the string loop away from you until it is in the notch of the top limb tip.



**10**  
The string should be centered on back of the limbs. Your bow is now ready to shoot.

*Archery for Anyone, Anywhere™*



*Visit our website  
for video tutorials  
and more!*

*Always unstring your bow when not in use.  
To unstring the bow, reverse the above process.*

**SAFEARCHERY.COM**